


The interior walls are attached with wood screws inserted horizontally into the cleat.




**DETAIL A**  
SCALE 1:5


Avoid anchoring in this corner as it can cause door drop.

Solid floor. One common anchoring method is through the floor after installation. This options would require the cleats to be reinforced with screws before install.

Another common anchoring technique is with a bracket mounted to ceiling into a stud wall. This option requires no modification to the booth. But the bracket must allow for a 4" space between wall and booth for adequate ventilation.



**DETAIL B**  
SCALE 1:9



Materials:

APPROVED	David Evans	1/15/2020
CHECKED	Keven Bricknell	1/15/2020
DRAWN	David Evans	1/15/2020

PROJECT			
<b>Comfort Booth Construction</b>			
TITLE			
<b>Construction Information For Seismic Anchorage</b>			
For information purposes only.			
SIZE	CODE	DWG NO	REV
B			1
SCALE 1:100	WEIGHT 500lbs.	SHEET 1/1	